

INSTRUCTION MANUAL

Models FH and FV Tension Transducers



5 YEAR WARRANTY



217 Pickering Road

Rochester, NH 03867-4630 U.S.A.

For assistance, please call:

TECHNICAL SERVICE - Installations, Start-Up, Troubleshooting, Repairs, Field Service, Returns. **techsupport@dfe.com**

CUSTOMER SERVICE - Replacement Parts, Individual Products, Questions about Orders, Manuals. **customerservice@dfe.com**

SALES - Product Information, Systems Application Questions, and placing orders for standard products and special systems. **sales@dfe.com**

Telephone: (603) 332-6150 Fax: (603) 332-3758

E-mail: info@dfe.com Internet: www.dfe.com

TABLE OF CONTENTS

SECTION ONE: DESCRIPTION AND OPERATION	PAGE
1.1 General Description	1
1.2 Mechanical Operation	1
1.3 Electrical Operation	2
1.4 Specifications	3
1.5 Standard Features	3
1.6 Options	3
SECTION TWO: INSTALLATION	
2.1 Dimensions	4
2.2 Pre-installation Requirements	5
2.3 Installing the Transducers	6
SECTION THREE: CALIBRATION AND SETUP	
3.1 Introduction	9
3.2 Connection to the Electronics	9
3.3 Zero the Tension Meter	9
3.4 Calibrate the Tension Meter	9
SECTION FOUR: CARE AND MAINTENANCE	
4.1 Removal of Roll and Pillow Blocks	10
4.2 Removing Transducers	10
SECTION FIVE: TROUBLESHOOTING GUIDE	11
SECTION SIX: REPLACEMENT PARTS	13
Appendices:	
A. Transducer Electrical Connections	14
B. Selection of Load Rating	15
C. Typical Tensions	17
Terms and Conditions of Sale	18
Index	19

FIGURES

1. FH Transducer Operation	1
2. FV Transducer Operation	2
3. Strain Gage Connections	2
4. Dimensions	4
5. Tension Zones	5
6. Minimum Shaft Length	6
7. FH Transducer Orientation	6
8. FV Transducer Orientation	7
9. Bearing Mounting Bolt Length	8
10. Web Path	9
11. Model F Transducer Wiring	14

1.1 GENERAL DESCRIPTION

The model F transducer is a heavy-duty flat transducer, designed to be used in pairs, to accurately measure web tension in machines having live (rotating) shaft idler rolls. The shaft rides in standard, industrial pillow block bearings mounted on each end. The bearings are then bolted to the transducer top plates. Typically used for high tension and/or high speed applications.

An F transducer consists of a single-piece aluminum base with a removable stainless steel top plate. A seal between the base and top plate prevents intrusion by dust, water, or other contamination. The transducer's electrical connector is located at the end of a short cable for easy access during installation. Each transducer contains two high-output semiconductor strain gauges connected in a half Wheatstone Bridge configuration. When two transducers are connected together, a full bridge is formed.

The model F transducer is available in a V (vertical) configuration or an H (horizontal) configuration. The V is used when the tension force is roughly perpendicular to the top plate of the transducer. The H configuration is used when the tension force is mostly parallel to the transducer top plate. The V and H configurations have identical outside dimensions, within each frame size. Two frame sizes are available; size 2 and size 3.

1.2 MECHANICAL OPERATION

1. The FH (Horizontal) Tension Transducer.

The FH Transducer can be installed in any position. But, when installed horizontally, the idler roll weight does not affect the output thereby increasing the effective range of the transducer.

Inside the transducer is a pair of cantilever beams having strain gages. The top plate is attached to the beams, and when moved in a direction parallel to the base, the beams bend a small amount creating an electrical output from the strain gauges. If the tension force is in the opposite direction from the arrow on the label, the electrical output will have reverse polarity.

Mechanical stops prevent damage from overloads. The stops are functional in both horizontal directions.




Figure 1 - FH TRANSDUCER OPERATION

2. The FV (Vertical) Tension Transducer.

The FV Transducer can be installed in any position.

The FV has a single beam with strain gages, and a hinge. Tension force from the top plate causes the beam to bend a small amount, allowing the top plate to pivot on the hinge at the connector end.

Mechanical stops prevent damage from overloads. The stops are functional in both vertical directions. Bending the beam a small amount creates an electrical output from the strain gauges. If the tension force is in the opposite direction from the arrow on the label, the output will have reverse polarity.




Figure 2 - FV TRANSDUCER OPERATION

1.3 ELECTRICAL OPERATION (see Figure 3)

The Model F Transducer is used in pairs, one on each end of an idler roll shaft. Web tension exerts a force on the roll which is transmitted to the beam by the top plate. Two semiconductor strain gauges are mounted on the beam. As force is applied and the beam deflects, one gauge is stretched and the other gauge is compressed. This increases the electrical resistance of the stretched gauge and decreases the resistance of the compressed gauge. The gauges in both transducers are electrically connected together in a Wheatstone bridge configuration. The bridge produces double the output of a single transducer and averages the outputs so web position, width and loose or tight edges do not affect the accuracy of the tension signal.




Figure 3 - STRAIN GAUGE CONNECTIONS

The physical location of the strain gauges, on opposite sides of the beam, ensures that each gauge experiences the same temperature variations. This, and the Wheatstone bridge configuration, provides automatic temperature compensation and a stable output.

The strain gauges are high output semiconductor devices which typically have an output sixteen times greater than the inexpensive foil gauges used in some transducers. Therefore, the signal amplifier used with these Model F transducers is a very stable low-gain design. An added benefit of the high output is inherent immunity to electrical noise. And semiconductor strain gauges have a very long life span.

1.4 SPECIFICATIONS

Electrical Specifications:

Excitation Voltage	5 Volts dc (10V with XR option)
Full Scale Output	250 mVdc nominal (500mVdc with XR)
Strain Gage Resistance	100 ohms nominal (200 ohms, XR)
Non-Repeatability	± 1/4% full span (FS)
Non-Linearity and Hysteresis Combined	± 1/2% FS
Temperature Range	-10°F to +200°F (-23°C to 93°C)
Electrical Connections	pin A....white wire..output
	pin B....black wire..... +/- 5V
	pin C....red wire..... - /+ 5V
Mating Electrical Connector	Amphenol MS3106A-10SL-3S

Mechanical Specifications:

Materials	303/304 stainless steel and aluminum
Load Ratings: Size 2	50 (V only), 100, 200, 400, 800, 1200 lbs. (225, 450, 900, 1800, 3600, 5350 N)
Size 3	1000, 2500, 5000 lbs. (4450, 11125, 22250 N)
Static Overload Capacity:	5 times load rating, minimum
Load Direction:		
H - horizontal	parallel to top plate ± 30°, away from cable end
V - vertical	+ / - 30° perpendicular to top plate, toward top plate
Weight: Size 2:	7 lbs. (3 Kg)
Size 3:	42 lbs. (19 Kg.)

1.5 STANDARD FEATURES

- Corrosion-resistant stainless steel and aluminum construction
- Sealed against dust and water
- Zero maintenance design; no wear- parts
- Attached cable with Amphenol connector, instead of connector mounted on device.
- Tethered top plate prevents separation from transducer in the unlikely event of beam failure.

1.6 OPTIONS

- **Drilled and Tapped top plate (D&T).** Top plate drilled and tapped for bearing.
- **Extended Range output (XR)** - Produces twice the output signal for a given load rating. Must be used with electronics having extended range option.
- **Oversized Top Plate (OTP)** - For mounting of oversized pillow block bearing.
- **Permanently Attached Cable (PT).** Permanently attached cable with tinned leads instead of Amphenol connector.

2.1 DIMENSIONS

SIZE		A	B	C	D	E	F	H	J	K	L	M	N	O	P	R	S	T	W
2	in	2.63	9.00	2.81	2.63	0.58	0.44	8.00	9.75	8.00	---	0.56	1.19	1.03	3.71	1.31	0.56	5.69	0.37
	mm	66.8	228.6	71.4	66.8	14.7	11.2	203.2	247.7	203.2	---	14.2	30.2	26.2	94.2	33.3	14.2	144.5	9.4
3	in	4.50	13.50	4.89	4.50	2.25	0.94	12.25	14.00	11.00	2.75	0.53	2.19	2.24	5.86	0.88	0.94	8.72	0.56
	mm	114.3	342.9	124.2	114.3	57.2	23.9	311.2	355.6	279.4	69.9	13.5	55.6	56.9	148.8	22.4	23.9	221.5	14.2




Figure 4 - DIMENSIONS

2.2 PRE-INSTALLATION REQUIREMENTS

A. TRANSDUCER ROLL

The Model F Transducers are used in pairs. One is mounted on each end of an idler roll shaft. The roll chosen is called the Transducer Roll.

1. **THE TRANSDUCER ROLL MUST BE A TRUE IDLER!** It can **NOT** be a driven roll! There can be **NO** brakes, clutches, belts, chains or gears attached to it or its shaft. It can not be a nip roll or be in contact with a nip roll. It can not be filled with water or have pipes or hoses attached to it. **NOTHING MUST CONTACT THE ROLL OR ITS SHAFT EXCEPT THE WEB!**
2. The Transducer Roll shaft is live (rotating). It must be designed and built for rotating service. Usually this means that it is straight, dynamically balanced and strong enough to resist bending from web tension forces.
3. The roll must be **DYNAMICALLY BALANCED** if web speed is over 300 FPM! Refer to **Section 2.3.3: BALANCE THE ROLL** for specifications. An unbalanced roll will reduce the accuracy of the tension signal.

B. TENSION ZONE

The roll must be located in the tension zone which is to be monitored or controlled. The beginning or end of any tension zone is always at a nip (driven or braked), unwind shaft, rewind shaft or drag bar. Any element in the web path that can change web tension is at one end of a tension zone.




Figure 5 - TENSION ZONES

C. WRAP ANGLE

The web must always contact the transducer roll in exactly the same way. The wrap angle must not change as the unwind or rewind roll diameter changes. Therefore there must be at least one idler roll between the transducer roll and the unwind or rewind shaft. If the machine has more than one webbing path, be sure to choose a roll that is wrapped the same for each. Otherwise it will be necessary to install an additional pair of transducers, or dual calibration circuitry, or both. If the wrap angle is allowed to change, the transducer output will change with angle as well as tension, and accuracy will be reduced. The transducer roll must be wrapped such that the resultant tension force is mostly parallel to the top plate of the FH transducer and mostly perpendicular to the top plate of the FV transducer.

D. MOUNTING SURFACE

The structure on which the transducers are mounted **MUST** be very stable and strong. Any movement of the structure may be sensed by the transducers and may cause inaccurate tension readings. The surfaces must also be smooth and flat so the transducers won't be uneven when they are installed.

2.3 INSTALLING THE TRANSDUCERS

Model F Transducers are very easy to install. Normally, both transducers are mounted on the machine and the roll is then installed on them. Follow the simple steps below.

1. DETERMINE SHAFT LENGTH

Measure the center to center distance between the transducer bases. Call this D_T . W is the width of one pillow block bearing. Use the following formula to determine the minimum shaft length:

For both FV and FH transducers: $\text{MINIMUM SHAFT LENGTH} = D_T + W$




Figure 6 - MINIMUM SHAFT LENGTH

2. MOUNT THE TRANSDUCERS ON THE MACHINE

To Mount FH Transducers:

Mount the transducers on the machine making sure that the transducers are facing in the direction of the tension force (See Figure 7) and the cables point in the same direction. The tension force arrow on the transducers denotes the proper direction for the transducers. The load force direction acts parallel to the top plate and should not exceed an angle of 30° with the top plate. Larger angles may result in unsatisfactory performance. To review load rating sizing formulas, see Appendix B.




Figure 7 - FH TRANSDUCER ORIENTATION

To Mount FV Transducers:

The FV transducer is designed to measure forces which are mostly perpendicular to the top plate (See figure 8). Mount the transducers on the machine making sure that the transducer force direction and mounting surface is the same as that used when the transducer load rating was sized for this application, and that the cable end of both transducers are on the same side of the roll. To review load rating sizing formulas, see Appendix B.

NOTE: To get expected results, be sure the installers are given the details of mounting orientation, connector end, and tension force direction. Application sketches are helpful.




Figure 8 - FV TRANSDUCER ORIENTATION

3. BALANCE THE ROLL

The roll must be dynamically balanced if web speed is 300 FPM or more. Balance the roll to Quality Grade G-2.5 as described in ISO 1940 and ANSI S2.19-75 standards. If these standards are not available, please contact **DOVER FLEXP ELECTRONICS** and we will provide the appropriate data.

4. SELECTION OF PILLOW BLOCK BEARING

The bearing must have self-aligning capability. The self-aligning feature will avoid unnecessary stress on the transducers caused by misalignment during installation and by roll deflection. One bearing must be installed so the shaft can move axially a small amount (float). The floating feature will avoid forces caused by temperature variations of the shaft. These factors could cause inaccurate output or damage the transducers. A 100° F temperature change causes approximately 0.077" change in length of a 10 ft. long piece of steel. The other bearing should not allow the shaft to float axially.

5. REMOVE THE TOP PLATE TO DRILL FOR THE PILLOW BLOCK BEARING

1. Remove the eight screws holding the top plate to the transducer. Be careful not to lose the "O" rings installed in the sealing plate. These are seals that keep out water. **Do not remove the red sealing plate under the top plate.**
2. Remove the top plate and drill and tap the holes for the pillow block bearing being used.
3. Replace the top plate and secure with the eight screws. Tighten the screws as follows: Size 2 to 7 FT-LBS of torque, Size 3 to 29 FT-LBS of torque.

6. INSTALL THE ROLL AND BEARINGS ON THE TRANSDUCERS

1. Place the bearings loosely on the roll shaft.
2. Place the bearings and roll on the transducers and mount the bearings to the transducers with the appropriate cap screws. The length of the cap screws should be sufficient to anchor the bearings, but not so long as to exceed the maximum thread engagement with the top plate (0.54" for the size F2, 0.92" for Size F3). If the cap screw is too long, the bearing will not clamp tightly to the top plate and the screw will interfere with force transfer to the sensing beam, and vibration and damage can occur. See Figure 9.

CAUTION! Do not use a bolt which is too long!




Figure 9 - BEARING MOUNTING BOLT LENGTH

3. Fasten the shaft in the bearings at this time. Be sure the floating bearing is installed with the axial gap on the side of the bearing facing the roll end so the shaft can grow in length as it gets hot, without causing stress on the bearing.

3.1 INTRODUCTION

There are no calibration adjustments on the Model F Transducer itself. The instructions below are for the electronics device which the transducers are connected to. All of the following terminology and procedures, assume that the transducers are connected to a **DOVER FLEXO ELECTRONICS** tension controller or tension indicator. If some other electronics are being used, you should follow the instructions furnished with it.

If your DFE electronic indicator or controller is equipped with Quik-Cal, then disregard these instructions and follow the instructions that came with the indicator or controller.

These are general instructions which are correct for most **DFE** controllers and indicators, and are placed here for your convenience. If you have any difficulty calibrating or if there is any discrepancy between these instructions and those in the Instruction Manual for the indicator or controller, you should disregard these instructions and follow the instructions in the Manual for the indicator or controller.

The transducers must be properly installed and oriented as directed in **SECTION 2.3**.

3.2 CONNECTION TO THE ELECTRONICS

Verify that the transducers are installed according to the instructions in sections 2.2 and 2.3 of this manual. Plug the transducer cords into the cables from the electronics device. Refer to Appendix A for connections if the device cables do not have connectors on the device end.

3.3 ZERO THE TENSION METER

1. Turn the "POWER" switch off. If the meter does not read zero, turn the mechanical adjustment screw on the meter face so the needle indicates zero tension.
2. Find an object that weighs at least 25% of the maximum value on the tension meter scale. (Be sure you know the exact weight).
3. Find a rope, tape, or wire that will support the weight in 2. above.
4. Verify that there is no web contacting the Transducer Roll. Turn the "POWER" switch on. Wait a few seconds for the tension meter to settle. Turn the "CALIBRATE" pot. to approximately 75%. Then, turn the "ZERO" pot. so the tension meter reads zero tension.

3.4 CALIBRATE THE TENSION METER

See Figure 10. Pass the rope over the Transducer Roll in exactly the same path as the web follows. Tie the end in the machine at least one idler roll beyond the Transducer Roll. Pass the other end by at least one idler roll before the Transducer Roll. Be sure the rope does not pass over any driven rolls, braked rolls or dead bars. (This will cause inaccurate calibration). Attach the weight to the free end of the rope and let it hang without touching anything. Turn the "CALIBRATE" pot. so the tension meter reads the same as the weight. Remove the weight and rope. This concludes the calibration procedure. Rope follows web path exactly. All rolls must be free-turning idlers.




Figure 10 - WEB PATH

Your Dover Flexo Electronics Model F Tension Transducers have been designed and manufactured to require no periodic maintenance. With proper application and installation your transducers will be maintenance-free and long-lasting. Any changes in your application which affect the dynamics of your equipment such as web speed, tension force, material, etc. could possibly require upgrading of load rating or a roll change. Contact Dover for specific information and engineering advice.

4.1 PROCEDURE FOR REMOVING ROLL AND PILLOW BLOCKS

To remove the transducers follow the procedure below to remove the roll and bearings from the transducers.

1. Support the idler roll so it won't fall.
2. Remove the bolts from the bearings on each transducer.
3. Take the roll and bearings off of the transducers.

4.2 PROCEDURE FOR REMOVING TRANSDUCERS

1. Disconnect the electrical cable on each transducer.
2. Remove the screws mounting the transducer and repeat for the opposite side.

This is a list of problems which could occur during initial start-up or afterwards. The probable causes are listed with the most likely one first and the least likely one last.

1. TRANSDUCER ROLL SHAKES, VIBRATES or BOUNCES

- a. Roll is not balanced. See Section 2.3.3 and Section 2.2.A.3.
- b. Shaft is not clamped tightly in bearings. Mounting screws are loose or shaft diameter is undersized.
- c. Transducer mounting bolts are not tight.
- d. Shaft is too weak or there is too much shaft extension between the roll ends and the transducers.
- e. Shaft is bent or too weak. (This refers to live shaft idler rolls, only)
- f. Roll is turning at its natural frequency. Call **DFE** for analysis of conditions and solution to problem.

2. CAN NOT ADJUST TENSION METER TO READ ZERO WHEN WEB IS SLACK

- a. Transducer roll is too heavy. See Appendix B for sizing formulas.
- b. Transducers are pre-loaded. See Sections 2.3.1 and 2.3.4.

3. TENSION METER READS BACKWARDS

- a. Transducers are installed backwards with force arrow pointing in opposite direction. See Section 2.3.2.
- b. Transducer cables are connected wrong at controller/indicator terminal strip. Signal wires are reversed.

4. TENSION METER NEEDLE PEGS HIGH OR LOW

- a. Meter is not electrically adjusted to zero. See Section 3.3, page 9.
- b. Transducers are pre-loaded. See Sections 2.3.1 and 2.3.4.
- c. Transducer cable has broken wire, poor connection or short circuit.
- d. A strain gage has failed. To verify: Unplug the transducer cable and use an ohm-meter to measure the resistance of the gages at the connector on the transducer. Measure between pins A,B, and A,C. In each case, the resistance should be about 100 ohms. Measure the resistance between any pin and the outside of the transducer. The meter should read infinite resistance. Apply a force to the roll by hand or by using a rope and a weight, in the direction of the tension force and maintain it while again measuring between pins A,B and A,C. The resistance should be only a few ohms different from before.
- e. Failure in the tension amplifier circuit of the controller/indicator.

5. TENSION METER DOES NOT READ ZERO WHEN WEB IS SLACK AND READING DRIFTS WITH TIME.

- a. Transducers are pre-loaded. See Sections 2.3.1 and 2.3.4.
- b. The structure the transducers are mounted on is weak. See Section 2.2.D.
- c. Transducer cable has a broken wire, poor connection or short circuit.
- d. A strain gage is cracked. Perform the test in 4d above.

6. TENSION METER DOES NOT READ THE SAME EACH TIME THE SAME FORCE IS APPLIED (poor repeatability)

- a. Transducers are pre-loaded. See Sections 2.3.1 and 2.3.4.
- b. The structure the transducers are mounted on is weak. See Section 2.2.D.
- c. The bearing or transducer mounting screws are loose.

7. TENSION METER READING DOES NOT CHANGE WHEN FORCE IS APPLIED TO ROLL. METER READS ZERO.

- a. Force direction arrow on one transducer is backwards. See Section 2.3.2.
- b. Transducer roll is too heavy. See Appendix B, page 15.
- c. Transducer cable has broken wire, poor connection or short circuit.
- d. Transducer cables connected incorrectly, or to wrong transducers.
- e. Failure of tension amplifier circuit in controller/indicator. Unit not turned on.

8. TENSION METER NEEDLE BOUNCES

- a. Web tension is fluctuating because of machine speed fluctuations, bent roll shafts, worn idler roll bearings, chattering unwind brake, flat spot in unwind or rewind roll, etc.
- b. Shaft is loose in the bearings. Bearing mounting screws are loose or shaft diameter is under-size.
- c. Transducer mounting bolts are loose.
- d. Tension controller is not adjusted properly. See controller Instruction Manual for procedure.

SECTION 6

REPLACEMENT PARTS

6.1 REPLACEMENT PARTS FOR THE F TRANSDUCER

PART	F2H	F2V	F3H	F3V
Top Plate	203-2692	203-2692	203-2808	203-2808
Top Plate Screws	123-0278 M5 x 16 Socket Head Cap		123-0065 M8 x 30 Socket Head Cap	
Cable	Not Replaceable - Factory Repair			
Instruction Manual:	Doc 801-2224			

Call **Customer Service** for prices and for part numbers of items not listed. For help with service or repairs, call **Technical Service**. We can be reached by the following:

Phone: 603-332-6150

Fax: 603-332-3758

E-mail: Customer Service: customerservice@dfc.com

Technical Service: techsupport@dfc.com

MODELS C, RS, AND F TRANSDUCERS

THE TENSION (T) AND COMPRESSION (C) STRAIN GAGES ARE CONNECTED IN A BRIDGE CONFIGURATION. AS THE BEAMS BEND SLIGHTLY UNDER WEB TENSION, THE GAGE RESISTANCES CHANGE PRODUCING AN OUTPUT SIGNAL WHICH IS DIRECTLY PROPORTIONAL TO THE WEB TENSION.

WIRES WITH DUPLICATE SIGNAL NAMES (2X +5V) (2X+5V) CAN BE PAIRED IN TERMINALS IF THERE ARE NOT 6 TERMINAL POSITIONS.




Figure 11 - MODEL F TRANSDUCER WIRING

SELECTION OF LOAD RATING FOR FH TRANSDUCERS

The Model FH Transducer is available in several standard load ratings, ranging from 100 lbs. (450 N) to 5000 lbs. (22250 N). The correct rating for any particular application depends on web tension, transducer roll weight, wrap angle and the direction of the tension force. Select the appropriate wrap configuration from the sketches below and apply the formula below the sketch.

- The Model FH transducer is sensitive to forces **parallel** to its top plate.
- Angle "D" should be as small as possible. Output will rapidly drop as D gets larger. Do not exceed 30°.
- If A = 0, idler weight will not produce any output signal.


Use the chart at bottom of page to select the correct load rating. In some cases, the load rating may be LESS than the calculated value. Sometimes the weight of a transducer roll uses up most of the operating range of the transducers. When this happens, it may not be possible to adjust the tension indicating meter to read zero when tension is zero

because the adjustment range of the electronic circuit has been exceeded. If the effective roll weight, represented by the "Wsin(A)" term in the formulas below, is more than 95% of the load rating chosen, the tension meter will probably not be adjustable to zero. If this is the case, one or more of the following changes must be made to reduce Wsin(A).


- Reduce the transducer roll weight.
- Decrease angle (A).
- Use the next higher load rating. (This is the least desirable choice because it reduces the transducer output signal).

Recommended Roll Weight Maximums:

- 100 lbs. load rating: 400 lbs. max. roll weight
- 200 to 400 lbs. load rating: 1000 lbs. max. roll weight
- 800 to 1200 lbs. load rating: 2500 lbs. max. roll weight
- 2500 lbs. load rating: 5100 lbs max. roll weight
- 5000 lbs. load rating: 11000 lbs. max. roll weight



$$\text{Load Rating} = \frac{4T \sin\left(\frac{B}{2}\right) \cos(D) - W \sin(A)}{2}$$



$$\text{Load Rating} = \frac{4T \sin\left(\frac{B}{2}\right) \cos(D) + W \sin(A)}{2}$$

- T = total maximum tension
- C = angle between entering and exiting web
- F_T = resultant force due to tension
- W = idler Roll weight
- B = wrap angle = 180° - C
- A = angle between line "V" and vertical direction
- D = angle between top plate and direction of force. Do not exceed 30° for best accuracy.
- "H" is a line parallel to top plate
- "V" is a line perpendicular to top plate

TABLE 1




ANGLE	SINE	COSINE
0°	0.000	1.000
5°	0.087	0.996
10°	0.174	0.985
15°	0.259	0.966
20°	0.342	0.940
25°	0.423	0.906
30°	0.500	0.866
35°	0.574	0.819
40°	0.643	0.766
45°	0.707	0.707
50°	0.766	0.643
55°	0.819	0.574
60°	0.866	0.500
65°	0.906	0.423
70°	0.940	0.342
75°	0.966	0.259
80°	0.985	0.174
85°	0.996	0.087
90°	1.000	0.000

Size	Calculated Load Rating (lb.)	Recommended Load Rating
2	up to 120	100 lbs (450 N)
	121 - 240	200 lbs (900 N)
	241 - 480	400 lbs (1800 N)
	481 - 960	800 lbs (3500 N)
	721 - 1440	1200 lbs (5350 N)
3	up to - 1200	1000 lbs (4450 N)
	1201 - 3000	2500 lbs (11125 N)
	3001 - 6000	5000 lbs (22250 N)

SELECTION OF LOAD RATING FOR FV TRANSDUCERS

The Model FV transducer is sensitive to forces **perpendicular** to its top plate. It is also available in several standard load ratings, ranging from 50 lbs. (225 N) to 5000 lbs. (22250 N). The correct rating for any particular application depends on web tension, transducer

roll weight, wrap angle and the direction of the tension force. Select the appropriate wrap configuration from the sketches below and apply the formula below the sketch. Use the chart at bottom of page to select the correct load rating.



Notes:

1. Angle "D" should not exceed 30° for best accuracy.
2. Wraps 2, 3, and 6 will produce an output signal which is opposite in polarity from normal. The transducer signal leads must be reversed at the controller or indicator terminal strip so the tension meter will read up-scale. **DO NOT REVERSE THE METER CONNECTIONS.**
3. If the W COS (A) term in equations for wraps 1, 2, 3, & 4 exceed 95% of the transducer load rating, use the next larger size transducer.

T = total maximum tension

C = angle between entering and exiting web

F_T = resultant force due to tension

W = idler Roll weight

B = wrap angle = 180° - C

A = angle between line "V" and vertical direction

D = angle between top plate and direction of force. Do not exceed 30° for best accuracy.

"V" is a line perpendicular to top plate

TABLE 1

ANGLE	SINE	COSINE
0°	0.000	1.000
5°	0.087	0.996
10°	0.174	0.985
15°	0.259	0.966
20°	0.342	0.940
25°	0.423	0.906
30°	0.500	0.866
35°	0.574	0.819
40°	0.643	0.766
45°	0.707	0.707
50°	0.766	0.643
55°	0.819	0.574
60°	0.866	0.500
65°	0.906	0.423
70°	0.940	0.342
75°	0.966	0.259
80°	0.985	0.174
85°	0.996	0.087
90°	1.000	0.000

NOTE:
Wraps 2, 3, & 6
will produce a
negative output.
See Note 2 above.

Size	Calculated Load Rating (lb.)	Recommended Load Rating
2	up to 120	100 lbs (450 N)
	121 - 240	200 lbs (900 N)
	241 - 480	400 lbs (1800 N)
	481 - 960	800 lbs (3500 N)
3	721 - 1440	1200 lbs (5350 N)
	up to - 1200	1000 lbs (4450 N)
	1201 - 3000	2500 lbs (11125 N)
	3001 - 6000	5000 lbs (22250 N)

Appendix C: Typical Tensions for Various Materials

TYPICAL TENSIONS FOR WEB MATERIALS			
ACETATE		0.5 lb. per mil per inch of width	
FOIL	Aluminum	0.5 lb. per mil per inch of width	
	Copper	0.5 lb. "	
CELLOPHANE		0.75 lb. per mil per inch of width	
NYLON		0.25 lb. per mil per inch of width	
PAPER	15 lb *	0.4 lb. per inch of width	
	20 lb	0.5 lb. "	
	30 lb	0.75 lb. "	
	40 lb	1.25 lb. "	
	60 lb	2.0 lb. "	
	80 lb	3.0 lb. "	
	100 lb	4.0 lb. "	
* based on 3000 sq. ft. ream			
PAPERBOARD	8pt	3.0 lb. per inch of width	
	12pt	4.0 lb. "	
	15pt	4.5 lb. "	
	20pt	5.5 lb. "	
	25pt	6.5 lb. "	
	30pt	8.0 lb. "	
POLYETHYLENE		0.12 lb. per mil per inch of width	
POLYESTER (Mylar)		0.75 lb. per mil per inch of width	
POLYPROPYLENE		0.25 lb. per mil per inch of width	
POLYSTYRENE		1.0 lb. per mil per inch of width	
RUBBER	<u>GAUGE</u>	<u>AT 25% STRETCH</u>	<u>AT 50% STRETCH</u>
	10 mil	1.75	3.68
	12 mil	1.10	2.03
	16.5 mil	4.09	8.17
	26 mil	2.47	4.97
SARAN		0.15 lb per mil per inch of width	
STEEL	<u>GAUGE - INS</u>	<u>UNWIND-PSI</u>	<u>REWIND-PSI</u>
	0.001 - 0.005	1000	4000
	0.006 - 0.025	850	3500
	0.026 - 0.040	750	3000
	0.041 - 0.055	650	2600
	0.058 - 0.070	550	2200
	0.071 - 0.090	450	1800
	0.091 - 0.120	450	1400
	0.121 - 0.140	400	1200
	0.141 - 0.165	400	1000
	0.166 - 0.200	400	900
	0.201 - 0.275	400	800
	0.276 - 0.380	300	700
VINYL		0.05 lb. per mil per inch of width	
*** For laminated webs, sum the tension for the individual webs and add 0.1 lb per inch of width.			

TERMS AND CONDITIONS OF SALE AND SHIPMENT

1. THE COMPANY

Dover Flexo Electronics, Inc. is hereinafter referred to as the Company.

2. CONFLICTING OR MODIFYING TERMS

No modification of, additions to or conflicting provisions to these terms and conditions of sale and shipment, whether oral or written, incorporated into Buyer's order or other communications are binding upon the Company unless specifically agreed to by the Company in writing and signed by an officer of the Company. Failure of the Company to object to such additions, conflicts or modifications shall not be construed as a waiver of these terms and conditions nor an acceptance of any such provisions.

3. GOVERNING LAW

This contract shall be governed by and construed according to the laws of the state of New Hampshire, U.S.A. The parties agree that any and all legal proceedings pursuant to this contract shall take place under the jurisdiction of the courts of the State of New Hampshire in the judicial district of Strafford County.

4. PENALTY CLAUSES

Penalty clauses of any kind contained in orders, agreements or any other type of communication are not binding on the Company unless agreed to by an officer of the Company in writing.

5. WARRANTY

Dover Flexo Electronics, Inc. warrants, to the original Buyer, its' products to be free of defects in material and workmanship for five years from date of original shipment. Repairs on products are warranted for 90 days from date of shipment. During the warranty period the Company will repair or replace defective products free of charge if such products are returned with all shipping charges prepaid and if, upon examination, the product is shown to be defective. This warranty shall not apply to products damaged by abuse, neglect, accident, modification, alteration or mis-use. Normal wear is not warranted. All repairs and replacements under the provisions of this warranty shall be made at Dover Flexo Electronics or at an authorized repair facility. The Company shall not be liable for expenses incurred to repair or replace defective products at any other location or by unauthorized persons or agents. This warranty contains all of the obligations and warranties of the Company. There are no other warranties, either expressed or implied. No warranty is given regarding merchantability or suitability for any particular purpose. The Company shall not be liable in either equity or law for consequential damages, losses or expenses incurred by use of or inability to use its' products or for claims arising from same. No warranty is given for products of other manufacturers even though the Company may provide these products with its' own or by themselves. The provisions of this warranty can not be changed in any way by any agent or employee of the Company. Notice of defects must be received within the warranty period or the warranty is void. The warranty is void if the serial number tag is missing or not readable.

6. PAYMENTS

Standard terms of credit are net 30 days from date of shipment, providing satisfactory credit is established with the Company. Amounts past due are subject to a service charge of 1.5% per month or portion thereof or 18% per annum. The Company reserves the right to submit any unpaid late invoices to a third party for collection and Buyer shall pay all reasonable costs of such collection in addition to the invoice amount. All quoted prices and payments shall be in U.S. Dollars.

If the Company judges that the financial condition or payment practices of the Buyer does not justify shipment under the standard terms or the terms originally specified, the Company may require full or partial payment in advance or upon delivery. The Company reserves the right to make collection on any terms approved in writing by the Company's Finance Department. Each shipment shall be considered a separate and independent transaction and payment therefore shall be made accordingly. If the work covered by the purchase order is delayed by the Buyer, upon demand by Company payments shall be made on the purchase price based upon percentage of completion.

7. TAXES

Any tax, duty, custom, fee or any other charge of any nature whatsoever imposed by any governmental authority on or measured by any transaction between the Company and the Buyer shall be paid by the Buyer in addition to the prices quoted or invoiced.

8. RETURNS

Written authorization must be obtained from the Company's factory before returning any material for which the original Buyer expects credit, exchange, or repairs under the Warranty. Returned material (except exchanges or repairs under the Warranty) shall be subject to a minimum re-stocking charge of 15%. Non-standard material or other material provided specially to the Buyer's specification shall not be returnable for any reason. All material returned, for whatever reason, shall be sent with all freight charges prepaid by the Buyer.

9. SHIPPING METHOD AND CHARGES

All prices quoted are EXW the Company's factory. The Company shall select the freight carrier, method and routing. Shipping charges are prepaid and added to the invoice of Buyers with approved credit, however the Company reserves the right to ship freight-collect if it prefers. Shipping charges will include a charge for packaging. Company will pay standard ground freight charges for items being returned to Buyer which are repaired or replaced under the Warranty. Claims of items missing from a shipment must be received, in writing, within 30 days of original shipment.

10. CANCELLATION, CHANGES, RESCHEDULING

Buyer shall reimburse Company for costs incurred for any item on order with the Company which is cancelled by the Buyer. Costs shall be determined by common and accepted accounting practices.

A one-time hold on any item ordered from the Company shall be allowed for a maximum of 30 days. After 30 days, or upon notice of a second hold, Company shall have the right to cancel the order and issue the appropriate cancellation charges which shall be paid by Buyer. Items held for the Buyer shall be at the risk and expense of the Buyer unless otherwise agreed upon in writing. Company reserves the right to dispose of cancelled material as it sees fit without any obligation to Buyer. If Buyer makes, or causes to make, any change to an order the Company reserves the right to change the price accordingly.

11. PRICES

Prices published in price lists, catalogs or elsewhere are subject to change without notice and without obligation. Written quoted prices are valid for thirty days only.

12. EXPORT SHIPMENTS

Payment for shipments to countries other than the U.S.A. and Canada or to authorized distributors shall be secured by cash in advance or an irrevocable credit instrument approved by an officer of the Company. An additional charge will apply to any letter of credit. There will also be an extra charge for packaging and documentation.

13. CONDITION OF EQUIPMENT

Buyer shall keep products in good repair and shall be responsible for same until the full purchase price has been paid.

14. OWNERSHIP

Products sold are to remain the property of the Company until full payment of the purchase price is made.

INDEX

Bearing, selection of	7	Options	3
Cables	3	Output	3
Calibration	9	Overload	3
Care and Maintenance	10	Pillow Block Bearing	6, 7, 8, 10
Description	1	Repeatability	3
Dimensions	4	Replacement Parts	13
Drill and Tap	3	Specifications	3
Dynamically balanced	5, 7	Strain gages	1, 2, 3, 14
Electrical connections	3, 14	configuration	1, 2
transducer	14	Temperature range	3
Electrical Operation	2	Tension Force	1, 2, 6, 7, 15, 16
Excitation Voltage	3	Tension Meter	
Extended Range	3	calibration of	9
Features, std.	3	zero of	9
Formulas, Load Rating	15-16	Tension Zone	5
Installation	4-8	Terms and Conditions	18
Linearity & Hysteresis combined	3	Top Plate	1, 2, 3, 4, 6, 13
Load direction	1, 2, 3	Transducer	
Load ratings	3	roll	5, 9, 10
selection of	15-16	balance	5, 7
Material	3	electrical connections	14
Mounting	6-7	Shaft length	6
bolt length	8	removal	10
positions	6-7, 15-16	Troubleshooting	11-12
surface	5	Typical Tensions	17
		Warranty	18
		Web path	5, 6, 7, 9
		Weight	3
		Wheatstone bridge	2, 3
		Wrap angle	5, 15, 16
		Zero	9



217 PICKERING ROAD
ROCHESTER, NEW HAMPSHIRE 03867-4630 U.S.A
TEL: 603-332-6150
FAX: 603-332-3758
E-mail: info@dfc.com Internet: www.dfc.com

CANADA

MEXICO

UNITED KINGDOM

EUROPE

TAIWAN

KOREA

AUSTRALIA

COLOMBIA

INDIA

SOUTH AFRICA

CHINA